



IN15, IN25M and IN40M Steam injectors


Installation and Maintenance Instructions



IN15



IN25M



IN40M

1. Safety information
2. General product information
3. Installation
4. Maintenance
5. Fault finding

IN15, IN25M and IN40M Steam injectors



1. Safety information

Pressure equipment not bearing the  mark is classified 'Sound Engineering Practice' in accordance with Article 3, Paragraph 3 of the European Pressure Equipment Directive 2014/68/EU.

It is the responsibility of the user to ensure that the product is installed and operated safely. Safe operation of these products can only be guaranteed if they are properly installed, commissioned, used and maintained by qualified personnel (see Section 1.11) in compliance with the operating instructions. General installation and safety instructions for pipeline and plant construction, as well as the proper use of tools and safety equipment must also be complied with. Detailed product information can be obtained from www.SpiraxSarco.com or by contacting your local Spirax Sarco sales office.

Note: By law, SEP products cannot be marked with the  symbol.

1.1 Intended use

- i) Check that the product is suitable for use with the intended fluid.
- ii) Check material suitability, pressure and temperature and their maximum and minimum values. If the maximum operating limits of the product are lower than those of the system in which it is being fitted, or if malfunction of the product could result in a dangerous overpressure or overtemperature occurrence, ensure a safety device is included in the system to prevent such over-limit situations.
- iii) Determine the correct installation situation and direction of fluid flow.
- iv) Spirax Sarco products are not intended to withstand external stresses that may be induced by any system to which they are fitted. It is the responsibility of the installer to consider these stresses and take adequate precautions to minimise them.
- v) Remove protection covers from all connections before installation.

1.2 Access

Ensure safe access and if necessary a safe working platform (suitably guarded) before attempting to work on the product. Arrange suitable lifting gear if required.

1.3 Lighting

Ensure adequate lighting, particularly where detailed or intricate work is required.

1.4 Hazardous liquids or gases in the pipeline

Consider what is in the pipeline or what may have been in the pipeline at some previous time. Consider: flammable materials, substances hazardous to health, extremes of temperature.

1.5 Hazardous environment around the product

Consider: explosion risk areas, lack of oxygen (e.g. tanks, pits), dangerous gases, extremes of temperature, hot surfaces, fire hazard (e.g. during welding), excessive noise, moving machinery.

1.6 The system

Consider the effect on the complete system of the work proposed. Will any proposed action (e.g. closing isolation valves, electrical isolation) put any other part of the system or any personnel at risk?

Dangers might include isolation of vents or protective devices or the rendering ineffective of controls or alarms. Ensure isolation valves are turned on and off in a gradual way to avoid system shocks.

1.7 Pressure systems

Ensure that any pressure is isolated and safely vented to atmospheric pressure. Consider double isolation (double block and bleed) and the locking or labelling of closed valves. Do not assume that the system has depressurised even when the pressure gauge indicates zero.

1.8 Temperature

Allow time for temperature to normalise after isolation to avoid danger of burns.

1.9 Tools and consumables

Before starting work ensure that you have suitable tools and / or consumables available. Use only genuine Spirax Sarco replacement parts.

1.10 Protective clothing

Consider whether you and/or others in the vicinity require any protective clothing to protect against the hazards of, for example, chemicals, high/low temperature, radiation, noise, falling objects, and dangers to eyes and face.

1.11 Permits to work

All work must be carried out or be supervised by a suitably competent person.

Installation and operating personnel should be trained in the correct use of the product according to the Installation and Maintenance Instructions.

Where a formal 'permit to work' system is in force it must be complied with. Where there is no such system, it is recommended that a responsible person should know what work is going on and, where necessary, arrange to have an assistant whose primary responsibility is safety.

Post 'warning notices' if necessary.

1.12 Handling

Manual handling of large and/or heavy products may present a risk of injury. Lifting, pushing, pulling, carrying or supporting a load by bodily force can cause injury particularly to the back. You are advised to assess the risks taking into account the task, the individual, the load and the working environment and use the appropriate handling method depending on the circumstances of the work being done.

1.13 Residual hazards

In normal use the external surface of the product may be very hot.

Many products are not self-draining. Take due care when dismantling or removing the product from an installation.

1.14 Freezing

Provision must be made to protect products which are not self-draining against frost damage in environments where they may be exposed to temperatures below freezing point.

1.15 Safety information - Product specific

Steam injectors operate at temperatures which could cause severe scalding, and produce strong currents of very hot water. Do not touch or lean over open tanks which are being heated, even if the water still appears to be cold. Ensure closed tanks are adequately vented and that the vent is unobstructed. Steam supply pipework must be firmly anchored to prevent vibration and stress in the tank wall. Tanks must be adequately constructed and braced/stayed as necessary to avoid vibration. Consult your local Spirax Sarco engineer if in any doubt.

1.16 Disposal

This product is recyclable and no ecological hazard is anticipated with its disposal providing due care is taken.

Please visit the Spirax Sarco product compliance web pages

<https://www.spiraxsarco.com/product-compliance>

for up to date information on any substances of concern that may be contained within this product.

Where no additional information is provided on the Spirax Sarco product compliance web page, this product may be safely recycled and/or disposed providing due care is taken. Always check your local recycling and disposal regulations.

1.17 Returning products

Customers and stockists are reminded that under EC Health, Safety and Environment Law, when returning products to Spirax Sarco they must provide information on any hazards and the precautions to be taken due to contamination residues or mechanical damage which may present a health, safety or environmental risk. This information must be provided in writing including Health and Safety data sheets relating to any substances identified as hazardous or potentially hazardous.

2. General product information


2.1 Description

Spirax Sarco steam injectors use steam to raise the temperature of water, generally in a tank. They can also be used to heat other liquids.

They work by using a jet of steam to draw in water through radial ports, mix it, and distribute the heated water throughout the tank.

The circulation induced by the injector ensures thorough mixing and an even temperature throughout the tank.


2.2 Pressure / temperature limits




The product **must not** be used in this region.

The product should not be used in this region or beyond its operating range as damage to the internals may occur.


Body design rating	PN25
Maximum saturated steam condition	19.4 bar g @ 213.41 °C
Maximum recommended heated water temperature (tank/vessel vented to atmosphere)	90 °C
Minimum operating pressure	0.5 bar g



IN40M
(available screwed or butt weld)



IN25M
(available screwed or butt weld)



IN15

Fig. 1 Steam injectors

IN15, IN25M and IN40M Steam injectors

3. Installation

3.1 General

IN25M (1") and IN40M (1½") are supplied in male thread (BSPT or NPT) or butt-weld form. They may be fitted to a tank wall connection or to pipework in the tank. It may be necessary to fit a reinforcing plate to the tank wall.

The IN15 has a 1" male thread for direct mounting to a tank wall and a ½" female thread for the steam supply pipework.

Do not use a wrench on the round body of an injector - ribs on the injector body allow a spanner to be used for fitting.

For higher capacities, two or more injectors may be fitted in parallel.




Fig. 2 IN25M/IN40M - Typical screwed installation direct to pipework




Fig. 3 IN25M/IN40M - Screwed coupling through tank wall




Fig. 4 IN25M/IN40M - Typical butt welded installation through tank wall (on a standpipe)




Fig. 5 IN15 injector - Typical installation through tank wall

3.2 Pipeline sizing

Use the same size pipe as the injector:-
15 mm pipe for IN15, 25 mm pipe for IN25M and 40 mm pipe for IN40M.

Pipe sizes for multiple injector installations are as follows:

No. of injectors	Type	Minimum pipe size
2	IN15	20 mm
2	IN40M	65 mm
3	IN40M	80 mm

IN15, IN25M and IN40M Steam injectors

3.3 Recommended layout

- Position the injector:
- horizontally,
 - at low level,
 - on the vertical centre line of the tank, (single injectors), a minimum of 150 mm from the side of the tank.
 - At one end of the tank.

The injector may be installed on a coupling through the tank wall, or on a short pipeline as close to the end of the tank as possible.

Pipework may be run inside or outside the tank. We recommend the use of a suitable thread locking compound on all threaded connections.


Discharge from the injector must be kept clear of any obstructions in the tank, e.g. pipework, stays, etc.

The distance between the injector and the end of the tank (L) must be as great as possible for quietest operation. The following minimum dimensions apply:

Steam pressure at injector inlet (bar g)	IN15 minimum length (L)	IN25M/IN40M minimum length (L)
0.5 - 7.0	250 mm	500 mm
7.1 - 10.0	300 mm	750 mm
10.1 - 14.0	350 mm	1 000 mm
14.1 - 17.0	400 mm	1 250 mm

A minimum depth of water must be allowed below the injector (H):

Injector type	Minimum dimension
IN15	100 mm
IN25M	150 mm
IN40M	200 mm



IN15, IN25M and IN40M Steam injectors

Multiple injectors

Position the injectors equally across the width (**W**) of the tank to ensure adequate mixing and maximum circulation. Leave at least 150 mm between the injectors and the tank side, and at least 300 mm between injectors.




Fig. 7 Two injector layout




Fig. 8 Three injector layout

3.4 Systems

A typical system is shown in Figure 9. All system parts should be fitted in a horizontal pipeline situated above the top of the tank. We recommend the fitting of a stop valve and a Y-type strainer upstream of the control valve. Install the strainer on its side to prevent a water pocket forming. Install the sensor and sensor pocket approximately one third of the way up the tank, ideally above, or above and to one side of, the injector(s). For boiler feedtank applications, keep the sensor well away from the cold make-up, condensate return, and flash steam inlets.

If used, install the dial thermometer near the sensor.




Fig. 9

4. Maintenance

No specific maintenance is required. Any temperature controller should be calibrated periodically. We recommend an annual inspection of the injector and the steam supply pipework. Check that the injector discharge holes are not obstructed and that any screw threads are tight. Check that the tank vent is clear. Clean any strainer in the injector system.

5. Fault finding

If correctly sized, controlled, and installed in a suitable tank, the steam injector(s) will operate quietly with minimum noise and vibration. **Noisy operation on installation** could be caused by inadequately braced pipework or loose connections.

Excessive noise and/or vibration in service is extremely unusual, but could be caused by an injector becoming loose or detached, or by one or more of the injector outlet nozzles becoming blocked.

Heavy vibration may occur if the tank temperature is allowed to exceed 90 °C, as the steam will not condense fully.

If severe vibration is experienced, do not continue to use the injector(s), or the tank may be damaged. Shut off the steam supply and investigate the fault immediately.

IN15, IN25M and IN40M Steam injectors



IN15, IN25M and IN40M Steam injectors

IN15, IN25M and IN40M Steam injectors

